

Computed Radiography System In-Line Erase

Part Numbers: D5000-DB and D5000-DRB

Operator's Manual







FOREWORD

Air Techniques and its ALLPRO Imaging division have prepared this document as a guide to the proper use of either the ScanX Discover and ScanX Discover HR Computed Radiography System In-Line Erase.

Refer to the following companion documents as necessary:

Document	Part Number
Imaging Plate Intensifier Screen Warning Instructions	73020
Phosphor Storage Plate Instruction Sheet	73474

TABLE OF CONTENTS

Section F	age
General Safety	. 3
Important Information	. 6
Introduction	
Purpose of this Manual	. 7
System Description	. 8
Unpacking and Inspection	
Technical Data	
Computer System Requirements	. 16
Abbreviations	. 17
Controls and Indicators	
System Setup	. 20
Plate Care and Preparation	
Imaging Procedures	
Powering Down the System	
Maintenance	
Warranty	. 29
On-Line Warranty Registration	. 29
Troubleshooting	. 30

IF YOU NEED ASSISTANCE

ALLPRO Imaging ScanX systems are designed and manufactured to high standards. They are easy to install and use and typically deliver high-quality performance. If any difficulties are encountered with this product, please contact ALLPRO Imaging Technical Support as follows:

- 1-800-247-8324 Monday through Friday 8:30 a.m. – 5:00 p.m. Eastern Standard Time
- 1-800-822-2899

Monday through Friday 8:30 a.m. – 5:00 p.m. Pacific Standard Time.

For additional information, please contact your authorized dealer or visit our web site, **www.allproimaging.com**

The ScanX has been designed to minimize exposure of personnel to hazards. While the equipment is designed for safe operation, certain precautions must be observed. Use of the ScanX <u>not</u> in conformance with the instructions specified in this manual may result in permanent failure of the unit.

General.

- Check with your dealer for packing material requirements if it is necessary to return the product to the manufacturer. Correct packing guarantees optimal safety of the device during transport. Should it become necessary to return the device to the manufacturer during the warranty period, the manufacturer will not accept claims for damage arising from using incorrect packing materials.
- Before every use, the operator must check the functional safety and the condition of the device.
- The operator must be knowledgeable in the operation of the device.

Use of Accessory Equipment.

The use of ACCESSORY equipment not complying with the equivalent safety requirements of this equipment may lead to a reduced level of safety of the resulting system.

Consideration relating to the choice shall include:

- use of the ACCESSORY in the patient vicinity.
- evidence that the safety certification of the ACCESSORY has been performed in accordance to the appropriate IEC 60601-1 and/or IEC 60601-1-1 harmonized national standard.

Use of ACCESSORIES or cables other than those specified or provided by the manufacturer may result in increased EMISSIONS or decreased IMMUNITY of the EQUIPMENT.

Do Not Attempt Internal Service.

The interior of each component of the ScanX System is only accessible by removing hardware with tools and should only be opened and serviced by an authorized dealer service technician.

Contact your local ALLPRO Imaging authorized dealer for service. Failure to heed this directive may result in equipment damage and voiding the warranty.

Electrical Safety Notes.

- The main power switch is the AC Mains disconnect device.
- Use only the line cord provided with the unit.
- Use only grounded electrical connections.
- To avoid risk of electric shock, fire, short-circuit or dangerous emissions, never insert any metallic object into the equipment.
- Only use connection cable(s) delivered with the device.
- Check the device cables for possible damage before switching on. Damaged cables, plugs and sockets must be replaced before use.
- Never touch open supply outlets and patients simultaneously.
- Do not locate unit where it could be sprayed with water, or in a damp environment.

Knowledge of Warnings and Cautions.

Users must exercise every precaution to ensure personnel safety, and be familiar with the warnings and cautions presented throughout this manual and summarized below. In this manual, the following definitions apply for all WARNINGS and CAUTION Statements:

WARNINGS: Any operation, procedure or practice, which, if not strictly observed, may

result in injury or long-term health hazards to personnel.

CAUTIONS: Any operation, procedure or practice, which, if not strictly observed, may

result in destruction of equipment or loss of effectiveness or damage to

equipment and Phosphor Storage Plates (PSPs).

DANGER: Opening the ScanX by removing any covers or components makes the equipment

into a Class III b Laser Product. [Class 3B Laser Product (IEC 60825)].

Warnings -

Only trained professionals should use this device. Federal law prohibits the sale of this device to individuals other than trained professionals. Use of this device, other than as described in this manual, may result in injury.

The ScanX contains a laser and is a Class 1 [Class 1 (IEC 60825)] Laser Product. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. The laser is on only during an active scan.

Only a trained technician from an authorized dealer should remove a cover from the ScanX. Direct eye contact with the output beam from the laser may cause serious damage and possible blindness.

Do not open the ScanX to maintain it. The ScanX contains no user serviceable parts. If there is a service problem, contact your authorized dealer.

Operate ScanX in dry environment. To prevent fire or electrical shock, do not expose this appliance to rain or moisture.

Equipment Disposal. Disposal of Scanx units, including internal batteries, electronic circuitry and PSPs must be accomplished only at the appropriate facilities for recovery and recycling. Make sure to dispose of such items in accordance with current federal, national, state and local government rules and regulations.

Cautions -

EMC Compliance Requirements. Use USB cables not exceeding 3m to connect between the computer and the scanner. Cable lengths greater than 3m may violate EMC compliance.

Stacking or using the scanner adjacent to other equipment may violate EMC compliance and interfere with the scanner operation.

Do not use damaged Phosphor Storage Plates (PSPs). Damaged PSPs may not provide reliable diagnostic images.

Cautions (Continued)-

Completely clean and erase PSPs before taking an X-ray exposure.

See the PLATE PREPARATION section of this manual.

Minimize exposing an X-ray exposed PSP to light. Transfer the PSP into the Inlet slot quickly to minimize exposure to light.

Use care in handling PSPs - Avoid fingerprints and scratching.

Refer to the instructions provided with the PSP package for further information on handling.

Use of other manufacturer's imaging plates. Do not put PSPs designed for drum-type or other scanners in the ScanX. The hooks and/or frames on the ends or around these PSPs, or PSPs of different thickness (especially thicker ones) will damage the ScanX. PSPs from another manufacturer may be used as long as the specifications are the same as those for the ScanX PSPs.

Contraindications. None known.

Markings.

The following terms or symbols are used on the equipment or in this manual to denote information of special importance:



The ScanX is a Class I Laser Product [Class 1 Laser Product (IEC)]

This warning label identifies the ScanX as such a product and describes the potential danger to humans in the event the product is opened during service. There is no laser radiation from this product when operated and maintained as instructed.

The Laser Product Accession Number is 0212282-00



Alerts users to important Operating and Maintenance instructions. Read carefully to avoid any problems.



Warns users that uninsulated voltage within the unit may be of sufficient magnitude to cause electric shock



Indicates that the unit conforms with WEEE Directive 2002/96/EC and must be disposed of only at the appropriate facilities for recovery and recycling.



Indicates that the ScanX complies with the Medical Device Directive 93/42/EEC.



Medical Device Safety Service Schiffgraben 41 30175 Hannover, Germany



Medical Electrical Equipment with respect to electrical shock, fire, mechanical and other specified hazards only in accordance with UL-60601-1, CAN/CSA C22.2 No.601.1 66CA

Manufacturer:

Air Techniques, Inc. 1295 Walt Whitman Road Melville, New York 11747 USA



Identifies the name of the manufacturer.



Indicates date of manufacture

Gene	eral Notes.
	All instructions in this manual form an integral part of the unit. They must be kept close to the unit and in readiness whenever required. Precise observance of these instructions is a pre-condition for use of the unit for the intended purpose and for its correct operation. This manual should be passed on to any future purchaser or operator.
	Safety of the operator as well as trouble-free operation of the unit are only ensured if use is made of original equipment parts. Moreover, use may only be made of those accessories that are specified in the technica documentation or that have been expressly approved and released by the manufacturer for the intended purpose. The manufacturer cannot warranty for the safety or proper functioning of this unit in the case where parts of accessories are used that are not supplied by the manufacturer.
	There is no guarantee against damage arising where parts or accessories are used that are not supplied by the manufacturer.
	Observe the usage and storage conditions.
	Appliances which accumulate condensation or become wet through a change of temperature may only be operated after they are fully dry again.
	The manufacturer regard themselves as being responsible for the equipment with regard to safety, reliability and proper functioning only if assembly resetting, changes or modifications and repairs have been carried out by an authorized dealer and if the equipment is used in conformity with the instructions contained in this manual.
	The device conforms to the relevant safety standards valid at this time.
Corre	ect Usage
	Only suitably qualified personnel may operation the ScanX.
_	The internal lithium-ion battery must be charged completely (at least 3 hours) prior to using for the first time. See page 21.
	The ScanX is only to be used in the processing of exposed PSPs.
	If the device is stored in a cool environment and brought to a warmer one, condensation can build up. Do not connect the device until it has warmed up to room temperature and is absolutely dry.
	The immediate working area should be free of all possible interferences (e.g. strong magnetic fields), as these could affect the operation.
	The ScanX may only be operated together with authorized software.
ā	Correct usage includes observing all adherence to the set-up, operation and maintenance instructions.
	Any use, above and beyond that described in this manual as correct usage, will invalidate the warranty.
Incor	rect Usage
	Any use that is not described in this manual as correct usage is considered as incorrect usage. The manufacturer is not to be held liable for any damage caused as a result of incorrect usage. The operator hears all risks

Congratulations on your purchase of the ScanX Discover or the ScanX Discover HR Computed Radiography System In-Line Erase, the latest portable imaging product from ALLPRO Imaging, a leading manufacturer of imaging systems for the medical, industrial and security markets. Each system has been designed and manufactured using state-of-the-art technology to produce the lightest, most portable, rugged and dependable digital imaging system available.

Designed and built exclusively for the demanding conditions encountered in portable radiography applications, either system is extremely easy to deploy producing excellent quality digital images in seconds. This efficiency coupled with repeatable consistent image quality provides results that allows the user to make critical decisions on the spot eliminating the need to return for retakes.

The ScanX Discover and the ScanX Discover HR are hereafter referred to as ScanX in this manual. Review and follow the guidelines included in this manual to ensure that your ScanX gives the highest level of service.







ScanX Discover HR

Figure 1. ScanX Discover and ScanX Discover HR Computed Radiography System In-Line Erase Models

PURPOSE OF THIS MANUAL

This manual provides the information necessary for the setup, operation and routine care and maintenance of the ScanX Discover and ScanX Discover HR Computed Radiography Systems In-Line Erase.

This manual is not to be used as a replacement for training in radiography. For information regarding the computer system and imaging software, refer to the appropriate documentation provided with your computer hardware and software.

General

The ScanX is a self-contained computed radiography (CR) imaging scanner/eraser system that utilizes reusable photostimulable or Phosphor Storage Plates (PSP) in place of X-ray film to produce quality digital radiographs. The PSPs are durable and reusable thousands of times. Upon exposure to X-rays, the plate stores a latent image, which is scanned by the ScanX. After scanning, the image is processed via the user-supplied computer running authorized software and ready for viewing in seconds. In addition to immediate display of the resultant images, the software allows image enhancement processing, storage (hard drive or CD), and sharing/retrieval.

An additional feature of the ScanX includes a patented in-line plate erase function that removes the latent image from the plate immediately after scanning. This design provides an efficient one-operation scanning and erasing process leaving the user with a PSP ready for the next X-ray procedure.

Both ScanX Discover models accept all brands of PSPs in all standard sizes and up to 14 inches wide by any practical length and shape.

The flexible and rugged design allows for the ScanX to be used on a counter top or for complete mobility, inserted into either an optional hard or soft carrying case for easy and safe transport anywhere image scanning is required.

A Discover Model to Suit Specific Needs

While each model is capable of processing phosphor storage plates (PSP) or imaging plates, the ScanX Discover and the ScanX Discover HR systems are designed to process the resulting images differently.

ScanX Discover: The ScanX Discover is optimized for high-contrast, medium resolution applications.

ScanX Discover HR: The ScanX Discover HR displays the highest resolution available when used with the appropriate photostimulable storage plate.

Rechargeable Battery

Both the ScanX Discover and Discover HR models have a built-in battery. This lithium ion rechargeable battery ensures up to 4 hours of standby readiness power, with up to 20 minutes of continuous ILE scanning operation, making the ScanX a truly portable computed radiography system suited for the rigors of field work applications.

ScanX Discover and Discover HR Features

View diagnostic X-ray images on your laptop, in seconds.
Make an on-the-spot analysis
Share inspection results with clients, anywhere, anytime.
Eliminates the need to return to the field for retakes.
Cushioned, lightweight extruded aluminum frame resists dents.
Sturdy, isolating/damping feet eliminate potential image quality issues due to vibration.
Patented, built-in eraser with manual or auto erase function.
Eliminate film, chemicals, processor maintenance, and the need for chemical storage and disposal.
Uses all brands of phosphor storage plates.
Accepts any brand of imaging plates up to 14" wide by any practical length, and custom shapes.
PSPs are flexible and wire-free; easily conforms to the object shape.
Works with various X-ray sources as well as Se 75, Ir 192 and Co 60.
High resolution digital images.
Adjustable settings for optimum dynamic range.
Operates in daylight.

Unpacking


As shown by Figure 2, the ScanX System is shipped in a single carton containing the ScanX main assembly and associated accessory kit. Unpack each component of the ScanX and inspect for physical damage such as scratched panels, damaged connectors, etc. If any damage is noted, immediately notify your ALLPRO Imaging authorized dealer immediately so corrective action can be taken. Save all cartons and packing materials to protect the ScanX in the event that it is to be transported or shipped in the future.

Included System Components

Each ScanX consists of the indicated main assembly and accessory kit as listed below. (See TECHNICAL DATA for ratings and identification for specific models.) Verify that all listed items were received. If any item is missing, notify your dealer.

System Components

Model	ScanX Discover P/N D5000-DB	ScanX Discover HR P/N D5000-DRB
Quick Start Instructions	D5421QB	D5421QB
Accessory Kit containing:	D5495B	D5496B
Fuse Kit (5A, 250VAC, 3AG Slo-Blo quantity 2)	D5469	D5469
Dust Cover	D5262	D5262
10-Foot Power Cord	61035	61035
6-Foot USB Cable	D5226	D5226
Brush Kit	D5027	D5027
Accessory Literature Kit:	D5495-LIT	D5496-LIT
Sample ScanX Cleaning Sheet Kit	B2030	B2030
CD Disk containing Drivers, Utilities and Operator's Manual	D5415	D5425



Electrical Requirements:

Supply Voltage: 100 to 240 VAC, 50/60 Hz

Supply Current: 2.5 A Maximum

Battery Fuse Rating: 5 A, 250VAC, 3AG, Slo-Blo

Line Cord: North American style 10 foot long Hospital

Grade power cord, P/N 61035

Country specific line cords are available

Physical Properties:LengthWidthHeightDimensions:18.0 inches15.5 inches14.0 inches(45.72 cm)(39.37 cm)(35.56 cm)

Weight: 46 lbs. (20.87 Kg)

Environmental Conditions:

Unit in Operation

Temperature: 20 to 115°F (-7 to 46°C) Humidity: 5% to 95% (Non-condensing)

Heat emission: <90W

Storage and Transport

Temperature: -21 to 130°F (-29 to 55°C) Humidity: 5% - 95% (Non-condensing)

Note: Resolution of the ScanX is dependent on operating mode and specific

imaging plate type used.

 Resolution (LP/mm)
 Vertical
 Horizontal

 Discover
 3.8 to 5.0
 3.8 to 7

 Discover HR
 3.8 to 14
 3.8 to 18+

Compliance Data:

Laser Classification: Class I Laser Product Compliance with

FDA HHS 21 CFR 1040.10 and IEC 60825-1

Laser Product Report

Accession Number: 0212282-00

IEC60601-1 Classification:

Class 1, Internally Powered Equipment, No Applied Parts, Transportable, Continuous Operation, Equipment not suitable for use in the presence of flammable anaesthetic mixture(s). Protection against ingress of liquids - Ordinary

Electromagnetic Interference:

Electromagnetic interference between the equipment and other devices can occur. Do not use the equipment in close conjunction with sensitive devices, or devices creating high electromagnetic disturbances.

The following provides the EMC technical data used to show that each ScanX is designed and manufactured to meet the electromagnetic requirements of International standard IEC 60601-1-2 as shown below. The user should ensure that the ScanX unit is indeed used within this environment to ensure that the system will perform as intended.

IMPORTANT: Mobile RF communications equipment can effect medical electrical equipment.

Medical electrical equipment require special precautions regarding EMC and needs to be installed according to EMC information.

Guide and Declaration by Manufacturer - Electromagnetic Emissions

The ScanX is intended to be used within the electromagnetic environment specified below. The user of the ScanX should assure that it is used in such an environment.

Emissions test	Compliance	Electromagnetic Environment - Guide
RF emissions CISPR 11	Group 1	The ScanX uses radio-electrical energy only for its internal subsystems. Therefore, it emits very low energy and is not likely to interfere with nearby electronic devices.
RF emissions CISPR 11	Class A	The ScanX can be used in all premises other than residential premises and premises connected directly to the public low-voltage power distribution
Harmonic emissions EN 61000-3-2	Class A	network used for powering residential buildings.
Voltage fluctuations/ flicker EN 61000-3-3	Applicable	

Guide and Declaration by the Manufacturer - Electromagnetic Immunity

The ScanX is intended to be used within the electromagnetic environment specified below. The user of the ScanX should assure that it is used in such an environment.

Immunity Test	IEC 60601 Test Level	Compliance Level	Electromagnetic Environment - Guide
Electrostatic Discharge (ESD) IEC 61000-4-2	± 6kV contact ± 8kV air	± 6kV ± 8kV	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%.
Electrical fast transient/burst IEC 61000-4-4	± 2 kV for power supply lines ± 1 kV for Input/output lines	± 2kV ± 1kV	Mains power quality should be that of typical commercial or hospital environment.
Surge IEC 61000-4-5	± 1 kV line(s) to line(s) ± 2 kV line(s) to earth	± 1kV N/A	Mains power quality should be that of typical commercial or hospital environment.
Voltage dips, short interruptions and voltage variations on power supply input lines IEC 61000-4-11	for 0.5 cycle <40% Ur (>60% dip in Ur) for 5 cycles 70% Ur (>30% dip in Ur) for 25 cycles	<5% Ur - 10ms <40% Ur - 100ms 70% Ur - 500ms <5% Ur - 5 s	Mains power quality should be that of typical commercial or hospital environment. If the user of the ScanX requires to continued operation during power mains interruptions in the main power supply, it is recommended that the ScanX be powered from an uninterruptible power supply or battery.
Power frequency (50/60Hz) magnetic field IEC 61000-4-8	3 A/m	3A/m	Power frequency magnetic fields should be at levels characteristic of a typical location within a typical commercial or hospital environment.

Note: Ur is the a. c. mains voltage prior to application of the test level.

Guide and Declaration by the Manufacturer - Electromagnetic Immunity

The ScanX is intended to be used in the electromagnetic environment specified below. The user of the ScanX should assure that it is used in such an environment.

Immunity Test	IEC 60601 Level	Compliance Level	Electromagnetic Environment - Guide
			Portable and mobile RF communication equipment should be used no closer to any part of the ScanX, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter.
			Recommended separation distance:
Conducted RF IEC 61000-4-6	3 Vrmsw 150 kHz to 80 MHz	3 V	d=1,16 √P
Rediated RF IEC 61000-4-3	3V/m 80 MHz to 2.5 GHz	3 V/m	d=1,16 \sqrt{P} 80 MHz to 800 MHz d=2,33 \sqrt{P} 800 MHz to 2.5 GHz
			where <i>P</i> is the maximum output power of the transmitter in Watts (W) according to the transmitter manufacturer and <i>d</i> is the recommended separation distance in meters (m).
			Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey, ^a should be less than the compliance level in each frequency ^b . Interference can occur nearby devices bearing the following symbol:

Note 1: At 80 to 800 MHz, the higher frequency range applies.

Note 2: These guidelines may not apply in all situations.

Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

- a. Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephone and land mobile radios, AM and FM radio broadcast, and TV broadcast can not be predicted theoretically with accuracy. To assess the electromagnet environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the ScanX is used exceeds the applicable RF compliance level above, the ScanX should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as re-orienting or relocating the ScanX.
- b. Over the frequency range 150 kHz to 80 MHz, field strengths should be less than $[V_1]$ V/m.

Recommended separation distances between portable and mobile RF communication systems and the ScanX Computed Radiography System In-Line Erase system

The ScanX is intended for use in an electromagnetic environment in which radiated RF interferences are controlled. The user of the ScanX can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the ScanX such as recommended below, according to the maximum output power of the communications equipment.

Maximum assigned output power of the transmitter	Separation distance as a function of the transmitter's frequency m			
W	150 kHz to 80 MHz	80 MHz to 800 MHz	800 MHz to 2.5 GHz	
	d=1,16 √P	d=1,16 √P	d=2,33 √P	
0.01	0.116	0.116	0.233	
0.1	0.366	0.366	0.736	
1	1.16	1.16	2.33	
10	3.66	3.66	7.36	
100	11.6	11.6	23.3	

For transmitters rated at a maximum output power not listed above, the recommended separation distance (d) in meters (m) can be established by using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating of the transmitter in Watts (W) according to the transmitter manufacturer.

Note 1: At 80 to 800 MHz, the higher frequency range applies.

Note 2: These guidelines may not apply in all situations.

Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

COMPUTER SYSTEM REQUIREMENTS

IMPORTANT: To operate the ScanX, it must be connected to a compliant Computer System,

and the computer must be loaded with an authorized Imaging Software. Contact your dealer for available Computer System and Software options.

Computer System Required Components

The Computer System (computer, monitor, etc...) and any related peripheral or other equipment, supplied by the user, or a third party, must comply with IEC 60601-1 and/or IEC 60601-1-1 harmonized national standards. The minimum computer system requirements necessary to operate the ScanX are listed below.

Operating System: Microsoft Windows XP Professional with

Service Pack 3 or later for an Intel 32-bit

processor; or

Microsoft Windows XP Professional 64-bit Edition with Service Pack 2 or later for an Intel 64-bit extended

(x64) processor; or

Microsoft Windows Vista Business, Enterprise, or Ultimate with Service Pack 1 or later for an Intel 32-bit or an Intel 64-bit extended (x64) processor.

USB Port/Version: USB 2.0 or later

Hard Drive: 500 GB (1GB available disk space

required to start scanning.)

Image Management Software: Compatible authorized third-party

software (not included with product).

Peripherals: CD-ROM Drive

Recommended Components

The items listed below are recommended (but not required) computer system components to aide in ScanX operation

CPU/Speed: 3.0 GHz Intel CORE2

System RAM: 2 GB

Monitor 20-inch SVGA, 1024 x 768 or higher

resolution, contrast ratio 450:1,

(1024 x 768 Resolution): .22 dot pitch capability.

Video Display Adapter: 32 MB RAM

Peripherals: Standard Keyboard & Mouse

Backup Device

External Surge Protector Power supply backup

System Properties.

If unsure of the operating system version installed, check that it meets the necessary requirements by checking the **System Properties** window.

This is done simply by right clicking the **My Computer** icon. Selecting **Properties** from the menu list displays the **System Properties** window as shown. The installed operating system version is listed under the **General** tab.

The System Properties window can also be opened from the Desktop Start button. Just press the Start button and select **Settings**→**Control Panel** and then click **System** icon.



ABBREVIATIONS

Abbreviations used in this manual are summarized below.

Α	ampere(s)	lux a m	easure of light intensity
AC	alternating current	MB	megabytes
CD-ROM	compact disk, read-only		$(2^{20} \approx 10^6 \text{ bytes})$
	memory	mm	millimeter (10 ⁻³ m)
CFR	Code of Federal	MONTH YYYY	date
	Regulations		(Month, 4 digit year)
CPU	central processing unit	Phosphor	a luminescent material
	(your computer)	PN	part number
cm	centimeter	PSP	photostimulable
GB	gigabyte (2³0 ≈109		phosphor plate
	bytes)		(imaging plate)
GHz	Gigahertz (10 ⁹ of Hertz)	RAM	random access memory
Н	height	RH	relative humidity
Hz	Hertz (cycles per second)	SVGA	Super Video Graphics
IEC	International Electro-		Array
	technical Commission	USB	Universal Serial Bus
IMS	lmage Management	UL	Underwriters
	Software		Laboratories
IP	imaging plate	V	Volts
LED	Light emitting diode	W	Watts, width
L	length	°C	degree Celsius
lbs	pounds	°F	degree Fahrenheit
lp/mm	line pair per mm	", in	inch




Figure 3. Power Panel Control and Connection Locations

Power Control Panel Control and Connection Functions

Item	Function
Main Power Switch (I/0)	A circuit breaker that controls the application of AC operating power and protects against shorts in the internal electrical circuits. Important: Must be set to the ON (I) position when charging the battery.
IEC Connector	Provides connection of supplied line cord for AC Mains outlet power input used for operation and battery charging.
USB Type B Connector	Provides USB connection from the computer via the supplied USB Computer Connector Cable.




Figure 4. Battery Power Control and Status Indicator Location

*IMPORTANT: Unless the ScanX is in use under battery power, the ON/OFF (BATTERY) switch must always be in the OFF position to prevent battery discharge, and/or allow re-charging.

Battery Control and Status Indicator Functions

Item	Function
SLO-BLO Fuse	This slow blow fuse protects the battery pack from excessive current conditions.
BATTERY ON/OFF Switch	A push button switch that controls the battery function as follows. 1. When set in the ON position (depressed and flush with the panel), this switch allows the ScanX to operate from battery power. While engaged, the CHARGE LEVEL Indicator illuminates 2. When placed in the OFF position (raised position), the switch removes the battery power preventing further battery discharge.
CHARGE LEVEL Indicator	 When the battery power is activated, this tri-color LED indicates battery status: Illuminates GREEN when there is approximately 10% and above of working battery charge capacity. Illuminates YELLOW when there is less than approximately 10% of working battery charge capacity. Recharging is recommended at this charge level. Illuminates RED momentarily and then extinguishes showing that the working charge capacity of the battery has been fully used.




Figure 5. Membrane Keypad and Indicator Locations

Membrane Keypad and Indicator Functions

Item	Function	
READY Switch	Toggles between the Standby and Ready mode as follows: 1. Press to switch from the Standby mode to the Ready mode. 2. Press and hold down for at least 2 seconds to switch to the Standby mode from the Ready mode.	
Ready/Standby Status Indicator (Green LED)	Illuminates green to indicate that the ScanX is Ready for operation. When extinguished, it indicates that the ScanX is in the Standby mode.	
ERASER Switch	Sets the erase function to operate in one of three modes: 1. Press the switch once to turn the erase function ON using one row of red LED erase lights. 2. Press the switch a second time to keep the erase function ON adding a second row of red LED erase lights. 3. Press the switch a third time to extinguish all red LED erase lights and turn the erase function completely OFF. The switch has no effect once the plate scanning operation begins.	
Note: When the Eraser Status Indicator displays a burst of approximately 5 quick flashes then extinguishes, it is alerting the user that an over temperature condition exists with the red LED erase lights.		
Eraser Status Indicator (Blue LED)	Displays the erase function status as set by the ERASER Switch: 1. Illuminates steady blue to indicate that the erase function is ON using one row of red LED erase lights. 2. Flashes blue twice to indicate that the erase function is ON using the two rows of red LED erase lights. 3. Extinguishes to indicate that the erase function is OFF and all red LED erase lights are extinguished.	
Scanner Track Status Indicators (Bi-Color LEDs)	Displays the scanner operational status: 1. Illuminates green when the Scanner has been activated, indicating that a PSP can be fed into the ScanX. 2. Illuminates yellow, indicating the PSP has been sensed and the Scanner is transporting the PSP.	

IMPORTANT: The Battery fuse must be installed in order to operate the ScanX battery.

Battery Fuse Installation

Install the supplied 5A fuse into the ScanX panel as follows:

- 1. Insert the fuse cartridge into the fuse holder hole.
- 2. Secure the fuse by twisting the fuse cap 1/4 turn clockwise.

Note: Authorized Imaging Software supplied by the dealer or other company, must be installed on the computer in order to operate the ScanX.

ScanX Drivers and Utilities Installation

Before connecting the ScanX to your computer or attempting to use it for the first time, run the Setup program on the ScanX Drivers and Utilities Disk included with the ScanX. Normally, this program runs automatically when the CD is inserted into the drive for the first time. If not, run the Setup program located in the root directory of the CD (typically **D:\AutoRun.exe**).

ScanX Initial Connection Procedure

Refer to Figure 6 and perform the following procedure to connect the ScanX for operation to a computer for the first time.

- Make sure that the computer meets all requirements (see page 16) necessary to support ScanX operation. Set up the computer according to the manufacturer's recommendations.
- 2. Verify that an authorized Imaging Software and the supplied USB drivers are installed properly on the computer.
- Connect the high speed USB cable between the USB Type B connector located on the ScanX panel and the USB Type A connector located on the computer.

Note: Connect the line cord to the ScanX prior to plugging the line cord into the Mains outlet

- Connect the line cord between the Mains outlet and the IEC connector located on the ScanX panel
- 5. Turn ON the main power to the ScanX by placing the Main Power switch on the Built-In Control/Connector panel to the ON (I) position. The scanner is now in the Standby mode
- 6. Switch the scanner from Standby to ON by pressing the membrane READY switch (也) located on the Membrane Keypad Panel on the top of the scanner. Verify that both the green and blue LED indicators above the READY and ERASER switches, respectively, illuminate.
- 7. With both the ScanX and computer turned on, Windows detects the ScanX as a new USB Device and the Found New Hardware Wizard will appear. Windows should automatically find the drivers installed from the ScanX Drivers and Utilities Disk.

Note: Connect the line cord to the ScanX prior to plugging the line cord into

the Mains outlet.

The main power switch is the AC Mains disconnect device.

AC Power Connection

Connect the line cord between the AC Mains outlet and the IEC connector as shown below to connect AC input power.

USB Computer Connection

Connect the supplied high speed USB cable between the USB Type B connector on the ScanX panel and the USB Type A connector located on the computer.

Note: The internal battery power continually charges as long as the external AC Mains power is applied via the Main Power switch..

Battery Charging

The internal battery must always be charged prior to using. To reach the full operational power level, charge for at least 3 hours before using for the first time and on subsequent uses. Refer to figure 6 and charge the battery by performing the following steps.

- 1. Connect the AC Mains line cord as shown below.
- 2. Place the Main Power switch to the ON (I) position and make sure that the BATTERY ON/OFF switch is set to the OFF position.
- 3. Allow the battery to charge for at least 3 hours to reach the full operational power level.
- Place the Main Power switch to the OFF (0) position and disconnect the AC Mains line cord.
- 5. Verify that the CHARGE LEVEL indicator illuminates green by depressing the BATTERY ON/OFF switch to the ON position. If the indicator does not illuminate green, refer to page 30 for Troubleshooting procedures.
- 6. Place the BATTERY ON/OFF switch to the OFF position to retain the charge for field use.




Figure 6. ScanX Connections

IMPORTANT: Make sure to wear gloves when handling PSPs.

Prior to performing the imaging procedure provided on the following pages, the user must be familiar with the care, handling and preparation of the PSP in order to ensure successful image scanning. Figure 7 shows a typical plate.




Figure 7. Typical Plate Configuration

☐ Do not crease PSPs. Avoid scratching or soiling PSPs. Do not store PSPs in a hot or moist area. Protect the PSPs from direct sunlight and ultraviolet rays. Pick up the PSPs using two fingers around the edges to avoid unnecessary contact with the plates. CAUTION: Use a Plate Protector for each plate.

PSPs may be exposed in cassettes and scanned without Plate Protectors, however, greater care must be exercised to not expose the PSP to light before scanning and to prevent the PSP from being

scratched or soiled.

Plate Protection

Handle PSPs with Care.

When storing or transferring PSPs use an X-ray Cassette for PSPs.

Plate Protector. A correct size Plate Protector should be used when handling PSPs so as not to scratch or soil the sensitive surface or nick the edges.

Cassettes must not contain intensifying screens when using PSPs.

X-ray Cassette. Place the PSP with the Plate Protector into the appropriate X-ray Cassette with the sensitive (front) side of the PSP towards the Tube-side of the cassette and close cassette

IMPORTANT: PSPs must always be erased prior to use.

Note: Use PSPs within 24 hours of last erasure. Repeat erasing process if PSPs have

been stored longer than 24 hours.

Erasing PSPs

Each PSP should be used (i.e. X-ray exposed and scanned) **within 24 hours** of erasure since natural radiation will add noise to the PSP. Erase PSPs by simply using the ScanX In-Line Erase Feature. Erasing of PSPs can be accomplished using one of two methods as follows:

Note: Both erasing methods will result in an erased PSP suitable for reuse. The user will not observe any difference in ScanX operation when using either method.

Method #1

Perform the Activate Scanner and the Scanning and Erasing Plates procedures on pages 24 and 25. Except when performing step 4 of the Activate Scanner procedure, select the Erase option from the installed authorized imaging software to activate the ScanX. This method does <u>not</u> scan the plate and no image will be acquired.

Method #2

Perform the Activate Scanner and the Scanning and Erasing Plates procedures on pages 24 and 25. This method scans the plate and the imaging software may acquire a "junk image" (scanned latent plate image) that should be subsequently deleted from the imaging software.

Cleaning Phosphor Storage Plates

For the best images, PSPs and Plate Protectors should be handled carefully and kept clean. Use specially formulated PSP Cleaning Wipes (P/N B8910) to clean all PSPs and Plate Protectors. These single-use extra soft, 100% polyester fabric wipes will not scratch or damage while safely removing dust, hair, dirt and smudges from the imaging surface. Use one wipe and clean plates as follows:

- As shown by Figure 8, gently wipe the PSP Cleaning Wipe over the dry Plate surface. Wipe back and forth and then in a circular motion
- Allow the plate surface to air dry. Make sure that the PSP is completely dry before re-using.



Figure 8. PSP Cleaning

Disposal of Phosphor Storage Plates

Consult with your federal, national, state and local government, for rules and regulations on disposal of Phosphor Storage Plates.

IMPORTANT: Make sure that the x-ray imaging technique conforms to the

intended application requirements/specifications.

Note: Cassettes must **not** contain intensifying screens when using PSPs.

Take an X-Ray Image

Put an image on the PSP by performing the following procedure.

- 1. Load cassette containing an erased PSP in a Plate Protector into the exposure device as previously done with film.
- 2. Take an exposure.
- 3. Bring the closed cassette housing the exposed PSP to the ScanX. The PSP is now ready to be scanned.

Activate Scanner

Refer to Figure 9 and activate the ScanX via AC power or the internal Battery power by performing the following procedures.

- Refer to Figure 6, make sure the ScanX is properly setup and perform either step a or b depending on power used.
 - a. Activation via AC Mains place **only** the Main Power switch to ON.
 - b. Activation via Battery Power place both the Main Power switch to ON and Press the BATTERY ON/OFF switch to the ON position (flush with the panel). Make sure the CHARGE LEVEL indicator illuminates.
- Switch the scanner from standby to ON by pressing the membrane READY switch located on the Membrane Keypad.

Note: Eraser mode is enabled as factory default. ScanX settings are retained as set in last scan field operation.

- Verify that both the green and blue LED indicators above the READY and ERASER switches illuminate.
- 4. Run the user-supplied authorized Imaging Software to activate the Scanner and to select the desired image type and resolution.
- 5. Verify that the four Scanner track status indicators illuminate green when the Scanner has been activated, indicating that a PSP can be fed into the ScanX. If the indicators do not light, refer to page 29 for Troubleshooting procedures.




Figure 9. ScanX Activation

Note: Only one exposed PSP can be fed into the ScanX at a time. The next PSP may be fed only after all four track status indicators change from yellow to green.

Scanning and Erasing Plates

Scan and erase an PSP in one operation as follows.

- 1. Orient the cassette so that the Tube side is facing down and the hinge is away from you.
- 2. Open the cassette and grasp the Plate Protector guide flaps to lift out the Plate Protector enclosed PSP. Pinch guide flaps between the thumb and index finger to prevent the PSP from sliding out of the Plate Protector. While minimizing exposure to ambient light, move it to the ScanX inlet with the sensitive (front) side of PSP towards the ScanX.
- 3. As shown by Figure 10, position the Plate Protector containing the PSP against the curved inlet, surface and hold it flush against the scanner inlet. A Plate Protector containing an exposed PSP narrower than 14 inches may be centered on the scanner inlet, making sure that it is aligned.




Figure 10. Feeding an Imaging Plate

IMPORTANT:

Make sure that the plate protector does not get pulled into the ScanX transport along with the PSP plate.

- 4. Gently slide the PSP and Protector assembly into the scanning slot until the Protector is stopped by both guide flaps resting on the inlet ring which further aids in alignment.
- 5. At this point, all four track lights will turn yellow, indicating the PSP has been sensed and the Scanner is transporting the PSP.
- 6. Observe that a red glow emanates from the scanner exit slot.
- 7. Repeat steps 1 through 6 to process additional PSPs as necessary. Another PSP may be fed into the ScanX when all four track indicator lights illuminate green.
- 8. Observe that the scanned PSP exits through the scanner arch. Since the ScanX default operation mode is with the erase mode enabled (blue LED indicator below the ERASER switch is illuminated or flashing), the PSP is erased and ready for reuse for a new image.
- 9. Observe that all transport status indicators illuminate green and the red glow from the exit slot extinguishes after the last PSP exits.
- 10. Retrieve the processed (scanned and erased) PSP for reuse or storage. Make sure not to scratch the sensitive surface or nick the edges when removing from the scanner outlet.
- 11. View and save the image using features of the user-supplied authorized Imaging Software.

IMPORTANT:

PSPs will <u>not</u> be erased after scanning when operating the ScanX with the eraser disabled. PSPs must always be erased prior to exposure to X-rays for new images.

Scanning Plates without Erasing

The ScanX can be operated with the in-line eraser feature turned off. When the eraser mode is disabled, the ScanX scans the same as when the eraser is enabled except that the PSPs are **not** erased after scanning. Scan an PSP without erasing the image by performing the following procedures.

1. Activate the scanner by performing the procedures on previous page.

Note: Always check that the eraser mode is disabled upon activation. The ScanX defaults to the mode last used at power turn off.

- 2. If necessary, disable the eraser mode of operation by pressing the ERASER switch located on the Membrane Keypad.
- Verify that the blue LED indicator located below the ERASER switch is extinguished to indicate that the Erase function is OFF. The PSP will <u>not</u> be erased after scanning.
- 4. Insert the PSP to be scanned into the ScanX by performing the Scanning and Erasing Plates procedures provided on the previous page.




Figure 11. Eraser Disable

Erase Only Mode

The ScanX can be used to just erase PSPs. This is done simply by selecting the <u>Erase</u> option (instead of Scan) from the installed authorized imaging software when activating the ScanX. During the Erase Only mode just the in-line eraser is activated. The PSP is transported through the ScanX as a normal scan but is <u>not</u> scanned. No image is acquired and the PSP is erased and ready for reuse as necessary. See Erasing PSPs on page 23.

IMPORTANT: Never power down the system during a scanning session.

ScanX Power Removal

The battery power on ScanX models operating from the built in battery should be turned off when not used for extended periods. ScanX models operating from AC Mains are designed to be left on continuously during the active day. At the end of the day, or whenever desired, power down the system as shown by Figure 12 and the following steps:

- 1. Place the ScanX in the Standby mode by pressing and holding the membrane READY switch on the Membrane Keypad (approximately 2 seconds) until the green LED above the READY switch extinguishes.
- 2. Verify that the READY indicator extinguishes.
- 3. Remove the power to the ScanX by performing one of the following steps depending on operating power used.
 - a. When operating from the battery, press the BATTERY push button to place the switch in the OFF (raised) position. Verify the CHARGE LEVEL indicator extinguishes.
 - b. When operating from AC Mains, place the Main Power switch to the OFF (0) position.




Figure 12. ScanX Power Shut Down

Maintenance Procedures

The ScanX is designed for many years of trouble-free operation. Maintenance as described herein is minimal.

IMPORTANT: Do <u>not</u> spray solvents or liquid directly on the scanner.

Cleaning the ScanX

Turn off the ScanX disconnect the line cord from the Mains wall outlet and disconnect the computer connection cable from the ScanX before cleaning. Wipe the outside surfaces with a soft paper towel dampened with a disinfectant solution or non-abrasive household cleaner. Be careful not to allow solvents to run or drip into the ScanX. This could cause damage to the ScanX. Allow to air dry before plugging in or turning back on.

Cleaning the Plate Transport

Over time, small debris and dust can accumulate in the plate transport mechanism causing a loss in image quality and possible damage to the PSPs. To ensure optimal performance of the ScanX, the plate transport should be cleaned at least once per week using a new ScanX Cleaning Sheet each time. Sample sheets are included with the ScanX.

Phosphor Storage Plates (PSPs)

PSP's are subject to "wear" on the black side during normal handling and use. They can appear scratched, while the sensitive blue or white side remains relatively "smooth". This scratched look on the black side has absolutely no effect on the quality of the image and should be expected under normal conditions. If the phosphor side is scratched make sure the plates are being handled properly and not being dragged from the ScanX tray area or other surfaces that could cause scratching of the plate. Make sure to review the Plate Care and Preparation information provided on page 22 of this manual.

Scheduled Maintenance

Like all precision products, the ScanX requires a certain amount of care on a regularly scheduled basis. A well-organized maintenance program aids dependable equipment operation and reduces problems to a minimum. Routine checks help to detect general overall wear, and replacement of parts can often be made before a problem occurs. Adherence to the maintenance schedule will ensure that the ScanX Digital Imaging System will continue performing at its best with uninterrupted service.

Understanding this, we have established three basic maintenance kits that will help insure continuous operation of the ScanX Digital Imaging System. The kits and their associated parts number along with the recommended performance schedule are listed below

IMPORTANT: All service requiring access to the interior of the ScanX must be performed only by an authorized dealer service technician with the proper training.

Service Requirement	Schedule	Kit Part No.
Replace 5A, 250VAC, 3AG Slo-Blo Battery fuse.	As Necessary	D5470
Replace dust/debris brush on inlet ring assembly.	1 year	D5940
Replace complete transport belt drive belt assembly.	4 years	B7794

Warranty - ScanX Equipment

The ScanX is warranted to be free from defects in material and workmanship from the date of installation for a period of one year. The ScanX is designed as a truly portable computed radiography system suited for use in remote field applications as well as in office environments.

If your ScanX cannot be repaired in the field and turns out to be defective due to faulty materials and/or workmanship within the warranty period, ALLPRO Imaging will arrange to replace the unit at its expense within two business days. ALLPRO Imaging will ship the Customer a replacement, factory refurbished ScanX. The Customer then returns (at ALLPRO Imaging's expense) the malfunctioning system back to ALLPRO Imaging in the same shipping container.

This ScanX Swap Warranty coverage is valid in the US and Canada only and applies provided the product is handled properly for its intended use, in accordance with its operating instructions. This warranty does not apply to damage due to shipping, misuse, careless handling or repairs by non-authorized personnel.

Upon determination of eligibility by ALLPRO Imaging's Technical Support personnel, the Customer must return the malfunctioning ScanX within 15 business days or Customer will be invoiced for the replacement ScanX. Any returned units become the property of ALLPRO Imaging. In case of replacement of the product, the Warranty Period will remain in effect for 6 months or for the remaining period of the original warranty; whichever term is longer.

The Warranty is void if installed or serviced by other than authorized service personnel. If unit fails, and the problem is determined to be caused by the lack of recommended scheduled maintenance as outlined in this Instruction Manual (i.e. worn Belt Drives or Brushes), this failure would not be covered. This warranty does not cover accessories.

ON-LINE WARRANTY REGISTRATION

Quickly and easily register your new ScanX Discover or Discover HR on-line. Just have your product model and serial numbers available. Then go to the ALLPRO Imaging web site, www.allproimaging.com, click the Warranty Registration link at the top of the page and complete the registration form. This on-line registration ensures a record for the warranty period and helps us keep you informed of product updates and other valuable information.

	Trouble	Possible Cause	Corrective Action
1	No power/No green light on membrane switch	 No battery power. Not plugged in. No power at Mains Outlet Battery fuse blown or not installed. The ScanX has not been turned on. Defective power supply 	 Check CHARGE LEVEL, charge battery as necessary. Check that the line cord is firmly plugged in. Make sure outlet is grounded and has power. Make sure that the battery fuse is installed. Make sure that the Main Power switch is set to ON. Call your authorized dealer.
2	Green, Blue or Yellow indicator light does not work.	Defective light or circuitry.	Call your authorized dealer.
3	Imaging Software does not recognize the ScanX when selected.	 Inadequate Computer System. The ScanX has not been turned on. The computer connection cable is loose or defective. The computer does not recognize that the ScanX is connected. ScanX hardware problem. ScanX Driver CD not run. 	Verify Computer System requirements (Page 16). Make sure that the READY switch is set to ON and the green indicator light is illuminated. Reconnect the cable. Check for tightness. Replace if necessary. Verify that the Setup program was correctly installed (Page 20). Call your authorized dealer.
4	Plate does not scan properly.	 The PSP was not pushed far enough into the ScanX. Worn transport belt or belt driver. 	Check the plate protector tabs and fully feed the PSP into the ScanX. Replace defective transport belt or belt driver.
5	No image appears after scanning. Important: Do not allow the PSP to be exposed to light between taking an X-ray and scanning with the ScanX.	 The PSP fed backwards (printed side towards ScanX). The PSP was erased prior to scanning. Hardware failure. X-ray source failed or low exposure. 	 Quickly re-feed the plate with the printed side out. If a substandard image results, retake image. Feed the PSPs into the scanner immediately and quickly after removal from the cassette. Call your authorized dealer. Call your authorized dealer.

	Trouble	Possible Cause	Corrective Action
6	Image is too dark.	PSP has been overexposed	Use software to adjust brightness. If this is not possible, retake image with proper (lower) exposure and a newly erased PSP. Make sure intensifying screens are removed.
7	Image appears skewed on monitor.	 PSP was fed skewed. Worn transport belt or belt driver. 	 When inserting PSP into feed slot, be sure to "feel" for resistance of light seal brush, align PSP, and then push down uniformly on top edge of PSP. Check the plate protector tabs. Replace defective transport belt or belt driver.
8	Image contains ghost images or shadows.	 PSP was not completely erased prior to use. Imaging Plate was exposed with the back facing the tubehead. PSP has been stored too long in cassette. Partial erasure of the image due to exposure to light during handling of the PSP 	 Make sure the ScanX is operating with both eraser strips turned on (blue LED indicator below the ERASER switch is flashing). Make sure the plates are inserted properly into the barrier envelope or cassette with the proper orientation to the X-ray source. Do not store PSPs in cassettes for more than 24 hours. Do not leave exposed PSPs in well lit areas. Transfer PSPs from their protective cassettes to the ScanX within one hour of exposure. Make sure red erasing light eminates from both sides of the ring.
9	Image shows artifacts or white or black lines.	 The PSP surface is not clean and has dirt, stains or scratches on it. ScanX plate transport path may contain an obstruction, debris or dust. 	Clean the PSP with PSP wipes (P/N B8910). Make sure to handle plates properly. Do not reuse the PSP if scratched or stained. Clean transport path using a ScanX Cleaning Sheet (P/N B2010 or B2020).

ALLPRO Imaging is a leading manufacturer of imaging systems for the medical, veterinary and security markets. Thousands of ALLPRO Imaging products have been sold globally, installed and serviced through our network of authorized dealers.

100 Plus
2010

- Accent[™]
- □ Polaris™
- ScanX[®] 12
- ScanX[®] 12 DVM
- ☐ ScanX[®] Discover
- lacksquare Scan $X^{ ext{\tiny R}}$ Duo
- ☐ ScanX[®] Fit
- ☐ ScanX[®] Quantum
- ScanX[®] Scout
- ScanX[®] Trek
- Visix[™]



1295 Walt Whitman Road, Melville, NY 11747-3062

Website: www.allproimaging.com

East Coast: 1-800-AIR-TECH (1-800-247-8324) • West Coast: 1-800-822-2899